


MOXYO

Power Bank Uptown™ P5200 Manual

Thank you for purchasing our mobile Power Bank Uptown™ P5200, a high capacity rechargeable battery capable of providing power to smart phones, tablets and other mobile devices. Please read the following carefully before using the product.



FCC Statement:

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.



● Specifications

Battery type: Lithium-ion battery

Battery Life Cycle: ≥ 500 cycles

Input: 5V/2A

Dual output: 5V/2.1A Max

Capacity: 5200mAh@3.7V (19.2Wh)


Unit Dimensions: 94*42*23mm

Using Temperature: 0°C~45°C


Charging Time: Approx. 4 hours

● Package Contents



- ① Power Bank
- ② USB to Micro USB Charging Cable
- ③ Owner's Manual



Power Bank(Pic.1)




USB to Micro USB
Charging Cable(Pic.2)






① Charging Your Power Bank

- Charge via Wall Adapter
(adapter sold separately)



- Charge via computer
(computer sold separately)






② Charging Your Devices Using the Power Bank

● Power on

-Shake to activate; device will turn off after 30 seconds of no use.

-Auto-on while connected




Suitable for USB-enabled products




Battery Check



③ Shake to activate



LED indicator



Remarks: ● LED light - on

○ LED light - off

Safety And Maintenance



- Do not expose power bank to fire or high temperature.



- Do not disassemble or short circuit the power bank.



- Do not expose power bank to moisture or high humidity.



- Discontinue use if you find liquid leakage, overheating or other unusual conditions, or if power bank is damaged.



For more details visit:

www.moxyo.com/owners-manual